

## **+QL1JG HEAD ASSEMBLY REPLACEMENT**

**TOOLS REQUIRED:** One Phillips Head Screwdriver. One very sharp blade

- 1: Turn water off at Isolation Tap located in cupboard at beginning of Blue/White hose
- 2: Turn Filter Tap on to drain system & place towels on cupboard shelf to catch any excess water when filter is removed
- 3: Remove Filter cartridge
- 4: Using a very sharp blade cut Blue/White hose off where it connects to the QL1JG Head Assembly
- 4a: Only if unable to do item 4. Remove hose from QL1JG Head Assembly as per attached instructions & cut approx.. 10mm off the hose
- 5: Loosen screws (DO NOT REMOVE) holding metal bracket to the cupboard wall
- 6: Remove metal bracket from the wall & remove from work area
- 7: Install hose into the new QL1JG Head Assembly (push hoses in until they stop) ensuring correct water flow. Arrow on top of QL1JG Head Assembly shows direction of flow
- 8: Locate metal bracket back on screws & tighten
- 9: Install filter cartridge back into new QL1JG Head Assembly
- 10: With Filter Tap open turn Isolation Tap approx.. half on letting water run through the system
- 11: Open Isolation Tap fully & let system flush for approx.. FOUR minutes
- 12: Check that no other leaks developed throughout the system

To Disconnect hosing:

Standard fittings, push the collet square against the face of the fitting by using fingers. With the collet held in position the pipe be removed.

